


INSTALLATION & OPERATION INSTRUCTIONS

INSTALLATION INSTRUCTIONS:

- 1- PLACE THE LADDER ON A FLAT SURFACE WITH THE STANDOFFS FACING UP.
- 2- LAY THE SLIDING PIPE ASSEMBLY IN THE CENTER OF THE SQUARE LADDER RUNGS WITH THE PULL LOOP AT THE TOP OF THE LADDER.
- 3- PLACE THE (2) PIPE CLAMPS OVER THE 2"Ø PIPE CENTERED ON THE FIRST AND THIRD RUNGS OF THE LADDER.
- 4- PLACE THE (4) "U" BOLTS OVER THE SQUARE RUNGS AND THROUGH THE HOLES IN THE PIPE CLAMPS.
- 5- TIGHTEN ALL THE "U" BOLT NUTS APPLYING 10 - 15 FT LB. TORQUE TO EACH.
- 6- VERIFY THAT THE EXTENSION ASSEMBLY IS ATTACHED SECURELY TO THE LADDER.

OPERATION INSTRUCTIONS:

- 1- TO ENGAGE THE SAFETY LADDER EXTENSION, GRASP THE LOOP HANDLE AT THE TOP OF THE SLIDING PIPE ASSEMBLY AND PULL STRAIGHT UP UNTIL THE ANGLE AT THE BOTTOM OF THE SLIDING PIPE PASSES THE SQUARE LADDER RUNG ON WHICH YOU WANT IT TO SEAT.
- 2- ROTATE THE SLIDING PIPE 180 DEG. AND LOWER THE ANGLE UNTIL IT SEATS SECURELY ON THE SQUARE LADDER RUNG.
- 3- VERIFY THAT THE EXTENSION IS SECURELY SEATED BEFORE STEPPING ONTO THE LADDER.



APPROXIMATE WEIGHT: 13 LBS.
MATERIAL: ALUMINUM

2	3/25/20	MG	MG	SLOTTED POST STOP WAS CHANGED TO BE L3X3X3/8
1	2/26/20	DAV	DAV	REDESIGNED BOTTOM OF POST
REV.	DATE	BY	CHK.	DESCRIPTION

INTERPRET DIMENSIONS AND TOLERANCES PER ASME Y14.5M

BREAK ALL SHARP CORNERS & EDGES

TOLERANCES UNLESS OTHERWISE SPECIFIED:
INCHES AND FRACTIONS:
<10' = ± 1/8
>10' = ± 1/4

COPYRIGHT © 2020
ALL RIGHTS RESERVED

wbdoors.com

RETROFIT SAFETY EXTENSION
FOR LADDER – ASSEMBLY DETAIL

DRAWN BY: RT	SCALE: 1=10	SHEET: 1 OF 2	DATE: 10/19/15
APP'D BY: RT	DWG. NO: 1000001804	SHEET SIZE: B	REV: 2